2.

→　　→　add camera

Camera Type　Network Camera

　URL　rtsp://192.168.31.28:554/stream1　　　　IP

Camera　RTSP/TCP Camera

　　OK