


PS.




※ ※

1. sudo bash
2. /cdrom/aicloud/tools/epcciot_cdisk sda

※ sda sdb

```
root@pc-72: /home/lubuntu
檔案(F) 動作(A) 編輯(E) 檢視(V) 幫助(H)
root@pc-72: /home/lubuntu
lubuntu@pc-72:~$ sudo bash
root@pc-72: /home/lubuntu# /cdrom/aicloud/tools/epcciot_cdisk sda
```

install ,



Revision #27

Created 18 October 2021 03:45:08 by Epower

Updated 7 September 2022 06:43:02 by Epower