

# 5.

Conference      Applications→Conference

Extension

 [Home](#) [Accounts](#) [Dialplan](#) [Applications](#) [Status](#) [Advanced](#) 192.168.31.222

---

**Conference** [BACK](#) [SAVE](#)

Conference is used to setup conference rooms with a name, description, and optional pin number.

|                    |   |
|--------------------|---|
| <b>Name</b>        | <input type="text" value="2111"/><br><small>Enter the conference name.</small>  |
| <b>Extension</b>   | <input type="text" value="2111"/><br><small>Enter the conference extension number.</small>                                |
| <b>Pin Number</b>  | <input type="text"/><br><small>Optional pin number to secure access to the conference.</small>                            |
| <b>Profile</b>     | <input type="text" value="default"/><br><small>Conference Profile is a collection of settings for the conference.</small> |
| <b>Flags</b>       | <input type="text"/><br><small>Optional conference flags. examples: mute deaf waste moderator</small>                     |
| <b>Order</b>       | <input type="text" value="000"/><br><small>Enter the order number.</small>  |
| <b>Enabled</b>     | <input type="text" value="True"/><br><small>Select whether to enable or disable the conference.</small>                   |
| <b>Description</b> | <input type="text"/>  |

Revision #2

Created 30 November 2021 03:32:44 by Epower

Updated 6 December 2021 06:00:42 by Epower