

1.

https:// Server IP :1111

1. LV

→ LV→

The screenshot displays the V8.113 storage management interface. The left sidebar shows the navigation menu with '儲存' (Storage) highlighted. The main area is titled '邏輯儲存 LV' (Logical Storage LV). A modal window is open for creating a new LV. The modal contains the following fields:

- LV 名稱 (LV Name):
- VG 名稱 (VG Name):
- 總容量 (Total Capacity): G
- 檔案格式 (File System):
- 格式化硬碟 (Format Disk): ☒
- 磁區同步 (Disk Synchronization): ☐
- 註解 (Comment):

The background table lists existing LVs:

ID	LV 名稱	VG	總容量	檔案格式	磁區同步	註解	掛載	增大	修改	刪除
1	home	vg1					31%			
2	vm	vg2					61%			
3	nfs	vg1					16%			
6	iso	vg1					49%			
7	ceph-mon	vg1					0%			
8	ceph-osd	vg1	20G	btrfs			1%			

2. iso

→ → ep-desktop

雲端下載

雲端下載設定

10 records per page

Search...

名稱	說明	版本	狀態
ep-desktop	1.8G	0.0 / 1.0	下載安裝

顯示第 1 至 1 項結果，共 1 項

← 上頁

1

下頁 →

3.

→ → OS ep-desktop

預設選單

啟用 ☒

OS ep-desktop

自訂參數


確認

取消

4.

→ →

設定

狀態 

啟用 ☒

LV 名稱

DHCP IP開始

DHCP IP結束

DHCP IP閘道

DHCP IP介面

1

2

確認

取消

Revision #11

Created 1 November 2021 03:03:58 by Epower

Updated 2 November 2021 00:53:37 by Epower